



*Internal installation*

*(Twin wall straight from top outlet)*

Terminal

Guy Wire Bracket

Roof Flashing

Storm Collar

Roof Support

Enclosure for loft space

Ceiling Support

Firestop Spacer

Enclosure for upper floors

Ceiling Support

Firestop Spacer

Twin Wall Length

Adaptor to Stove

Stove